


HMFA-S

1. REFER TO ASY-083 FOR HYPERMAXI INSTALLATION.

2. HYPERMAXI UPRIGHTS SHOULD BE PLUMB. INSTALL HMFA-S AS SHOWN USING 5/16-18 X 2 1/2" BOLTS AND NUTS. HARDWARE FOR ANCHORING TO CONCRETE SHALL BE SUPPLIED BY THE INSTALLER. MINIMUM ANCHOR DIAMETER REQUIRED IS 1/4" AND MINIMUM EMBEDMENT IS 1 1/8"

 INSTALLATION INSTRUCTIONS <small>THIS SUPPLIER PREEXISTING MATERIAL IS EXCLUSIVELY THE INTELLECTUAL PROPERTY OF MADIX INC. ALL RIGHTS ARE RESERVED BY MADIX INC. © 2017 20984 AL HWY 9 GOODWATER, AL 35072 256-839-6354 PO BOX 729 TERRELL, TX 75160 214-515-5400</small>		DWG NO.:
		ASY1-289
		CHANGE #:
		500000019404
DESC: HMFA/ HYPERMAXI ANCHOR		REV. 01
DATE: 20170824	DESIGNER: NDOTSON	SHEET 1 OF 1