

EXTENSION UPRIGHT

ASY 018

INSTALLATION INSTRUCTIONS

- 1** Remove upright caps (if any) by inserting screwdriver into top slot of upright and prying up.
- 2** IMPORTANT! Insert pencil, screwdriver, or similar object completely through upright at SEVENTH SLOT from the top. THIS IS TO PREVENT CONNECTOR FROM ACCIDENTALLY FALLING TO BOTTOM OF UPRIGHT.
- 3** Loosen the three screws of extension upright connector... USE 1/8" ALLEN WRENCH (NOT PROVIDED).
- 4** Insert connector into top of upright and seat extension upright against upright.
- 5** Tighten the three screws, remove pencil from seventh slot... REPEAT STEPS 2 THROUGH 5 WITH REMAINING EXTENSION UPRIGHTS.
- 6** If backs will be inserted, skip to step 8.
- 7** Replace upright caps and snap on extension upright end covers, if any.



