


# ASY FOR SEISMIC Z BAR


**! YOU MUST USE TWO (2) SEISMIC Z-BARS FOR EACH SECTION! DO NOT OVER TIGHTEN BOLTS. HAND TIGHTEN WITH SCREWDRIVER ONLY. CORRECT TORQUE IS APPROXIMATELY 25-30 LBS**



LOCK NUT



SCREW  
FLAT WASHER



**DETAIL "A"**


HARDWARE PACK FOR EACH Z-BAR INCLUDES:  
 2 - SCREWS 1/4-20x2-3/4"  
 2 - LOCKING NUTS  
 2- 5/16" FLAT WASHER

1) ATTACH ONE Z-BAR APPROXIMATELY 7-1/2" FROM TOP OF UPRIGHT USING PROVIDED HARDWARE.

**DO NOT OVERTIGHTEN. DOING SO COULD PREVENT BACK PANELS FROM BEING INSTALLED PROPERLY.**

2) ATTACH 2ND Z-BAR APPROXIMATELY 16" FROM BOTTOM OF UPRIGHT.

NOTE ORIENTATION OF Z-BARS WHEN INSTALLING. MAKE SURE TRIANGLE IS LOCATED ON TOP. SEE DETAIL "A".



Z-BAR APPROXIMATELY 7-1/2" FROM TOP

PARTS NOT SHOWN:  
 BACK  
 UPPER SPANNER  
 LOWER SPANNER

Z-BAR APPROXIMATELY 16" FROM BOTTOM

UPRIGHT

BASE SHOE



© 2013 Madix Inc., All rights reserved  
 20884 AL HWY 9 GOODWATER, AL 35072  
 P.O. BOX 729 TERRELL, TX 75760  
 256-659-6554 / 214-515-5607 / 800-776-2349

SHEET 1 OF 1

ABASSETT  
 20131111

REV. 02  
 ECM # 500000013791

1

2

3

4

1

2

3

4